




## Includes 26 SEGA Genesis Games

### FIRECORE™ Arcade Master Deluxe

## INSTRUCTION MANUAL



© 2008 AtGames Holdings, Ltd.  
All rights reserved.  
Made in China.

Game software © SEGA Corporation. All rights reserved. SEGA, the SEGA logo and GENESIS are either registered trademarks or trademarks of SEGA Corporation.  
Distributed by AtGames under license from SEGA Corporation.

The content of this document is subject to change without notice.


Game software ©Capcom Entertainment, Inc. All rights reserved.

### Specification

Power Supply	100-240V AC
Special Features	Built-in 26 SEGA 16bit Games

### TV Game Console Appearance and Key List

The image below shows the location of the connectors and buttons. Each of its function is outlined below. (The illustrations are for reference only.)



- 1** Power ON/OFF  
Turn the TV game console's power ON/OFF.
- 2** LED (Power-On Light)  
It lights up when power is on
- 3** MENU  
Press this button to display game menu.
- 4** START/PAUSE  
Push to start a game and push again to pause a game
- 5** A Key  
Game key A
- 6** B Key  
Game key B.
- 7** C Key  
Game key C
- 8** X Key  
Game key X.
- 9** Y Key  
Game key Y.
- 10** Z Key  
Game key Z.
- 11** SD Card Slot  
SD card slot.
- 12** Joystick  
Joystick for game playing.
- 41**
- 42**
- 43**
- 44**
- 45**
- 46**
- 47**
- 48**
- 49**
- 50**
- 51**
- 52**
- 53**
- 54**
- 55**
- 56**
- 57**
- 58**
- 59**
- 60**
- 61**
- 62**
- 63**
- 64**
- 65**
- 66**
- 67**
- 68**
- 69**
- 70**
- 71**
- 72**
- 73**
- 74**
- 75**
- 76**
- 77**
- 78**
- 79**
- 80**
- 81**
- 82**
- 83**
- 84**
- 85**
- 86**
- 87**
- 88**
- 89**
- 90**
- 91**
- 92**
- 93**
- 94**
- 95**
- 96**
- 97**
- 98**
- 99**
- 100**

1

### How to play Arcade Joystick build-in games?

1. Connect the Arcade Joystick console to TV using the enclosed AV cable.
2. Press the "ON/OFF" button to "ON" to turn on.
3. Set your TV set's input source to "video in", and the main menu will show in your TV screen.
4. Use Joystick to direction "Up" or "Down" to select a game, then press the "START" button to enter the selected game.
3. Press the "START" button again to start playing game.

**Note:** For Plasma & LCD TV's over 32" , please adjust your TV to the following setting for the best display effect.  
Back-Lighted: 100  
Brightness: 36  
Contrast: 70  
Color: 60  
Sharpness: 60  
Aspect Ratio: 16:9

### How do you switch back to game menu while playing the game?

Press "MENU" key, and the screen will go back to the game menu page.

### How to play the games on your SD card?

1. Turn off the console.
2. Insert the SD card into the SD slot.
3. Turn on the console
4. Select "SD CARD" on the last page of menu, press start. You will then enter a menu page of the games in the SD card.
5. Select a game and press "START/PAUSE".

### How to add games to SD?


1. Insert SD card to PC.
2. Create a folder with the name of "Game"
- (if the SD doesn't have a "Game" folder already.)
3. Place games in the "Game" folder.

NOTE: Please do not insert/remove the SD card while the power is turned on. It may damage the game player. File names must be ended with ".bin"

### How do you turn off the Arcade Joystick console?

Press the "ON/OFF" button to "OFF" to turn off the game console.

### Alex Kidd in the Enchanted Castle



Alex Kidd's father's life is in danger! Fortunately, facing danger is what Alex does best! To save his father, he must win round after exciting round of "Paper, Rock and Scissors". Winning rounds not only moves Alex that much closer to his father, but winning also provides gifts that Alex can utilize for special powers. These will be necessary as the opponents get harder and harder and the danger increases! If Alex can win the ultimate level, he can save his father and win amazing prizes as well! There is not time to lose!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Select the tool in tool menu.

**A Key:** Jump up and kick.

**B Key:** Attack by fist.

**C Key:** Jump up and kick.

### Arrow Flash



Things are grim. An evil dragon from another galaxy is rapidly approaching Earth and as a space pilot, you realize that it is up to you to stop this threat cold. If you fail, your home will be burnt to a cinder. Your ship provides two distinct modes, each known as an Arrow Flash. Using blast weapons and defensive shield capabilities, your challenge is formidable. Hit the thrusters; you have a date with a dragon in outer space!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Transform into Planet or Robot mode.

**B Key:** Shoot.

**C Key:** Attack enemies with laser while transforming into planet.

Attacks enemy with speeding bullet while transforms into robot.

3

### Alien Storm



Strange and deadly aliens have invaded the earth and it is up to you to stop them! Your battle will take you through numerous environments as you fight your way to the mother-ship to face off with the "mother of all aliens". Each character has unique attacks and special abilities that will add strategic variety to your game play. Additionally, mission objectives provide opportunities for exciting power-ups. It will take all your skills to save the Earth!

**Directional Pad (D-Pad):** Control the direction.

Press the Right Key twice to make hero run.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Powerful attack in wide area which takes a lot of energy.

**B Key:** Attack in medium power.

Press to attack while in sprint status.

**C Key:** Toss forward.

Press to jump while in sprint status.

### Altered Beast



In a time of legend, warriors and supernatural foes, Zeus, God of Thunder, summons you from the dead as his champion in the fight of good versus evil. Athena, daughter of Zeus, has been imprisoned by the evil Neff, God of the Underworld, and it is your charge to free her from his clutches. To do so, you must battle Neff's henchmen until you reach the ultimate challenge. Zeus has given you one advantage: the ability to capture spirit balls which you can use to transmute into various beast forms. If you succeed, Zeus will be your ally for all time. If you fail, only Neff knows what pain will be your fate!

**Directional Pad (D-Pad):** Control the direction.

Press the Right Key twice to make hero run.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Powerful attack in wide area which takes a lot of energy.

**B Key:** Attack in medium power.

Press to attack while in running status.

**C Key:** Toss forward.

Press to jump while in running status.

4

### Chakan: The Forever Man



Chakan is a demon hunter who had a mission: defeat the Angel of Death in single combat. What he did not realize was that in doing so he would lose his soul! Cursed with life eternal, Chakan realizes that the only way to regain it and rest in peace is to eradicate the Earth of all evil. Fighting through many levels of platform-style action, Chakan will not rest until he has cleansed the Earth and his soul has been regained! Your soul calls out to you; heed its call!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Negative.


**B Key:** Attack by Knife.

Long press this key with D-pad to control knife waving.

**C Key:** Jump.

Press twice to jump again while jumping.

### Comix Zone



In this action thriller, you play the part of Sketch, a highly-respected comic book artist who, by a strange twist of fate, gets sucked into his own comic book creation. Stuck in a familiar world, you must become the hero, fighting against the very villains of your own imagination! If Sketch can first stop one of his evil characters from taking over the world, surely he will be able to find a way out of the real world!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Attack.

**B Key:** Jump.

**C Key:** Defense.

**X Key:** Use the tool from the left icon in the above.

**Y Key:** Use the tool from the middle icon in the above.

**Z Key:** Use the tool from the right icon in the above.

5

### Columns



Addictive and ancient, Columns is the game of a bygone era, originating with Phoenician merchants. Align puzzle pieces to build columns and bring them down. Easy to play, yet challenging to master, this is a game to keep you amused for hours on end. You will quickly understand why this simple puzzler has stood the test of time. Prepare to lose yourself in this game of the ancients.

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Arrange the item.

**B Key:** Arrange the item.

**C Key:** Arrange the item.

### Columns III



Columns III is the final game in the series of fast-moving puzzle classics. As in the other games in the series, match colors of dropping objects in order to remove them from the play field; if they rise to high, the game is over. Columns III adds multiple versions for strategic additions to keep the game fresh and exciting. This is the puzzle game that started it all!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Attack the competitor for shortening the space.

**B Key:** Arrange the item.

**C Key:** Attack the competitor for shortening the space.

6

### ESWAT: City Under Siege



Liberty is a dark, crime ridden metropolis, teaming with criminals who are looking to take advantage of the innocent and the weak. ESWAT places you in the game as a member of the Cyber Police force where it is your job to protect the citizens and stop the criminals. As you advance through this action-shooter, you will gain rank which will open up new weapons and defensive capabilities. If you can arrest the criminal masterminds behind the city's trouble, Liberty may even promote you to chief of the famed ESWAT squad! Look out criminals; ESWAT is on patrol!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Jump.

File while in armored mode.

**B Key:** Shoot.

**C Key:** Jump.

Fly while in armored mode.

### Flicky



When the babies wander off, there is only one thing to do: lead them back to the safety of their nest. Flicky the mother blue jay has just such a task. It won't be easy to get the baby chicks back though! Hungry cats on the prowl and many surprising hazards waiting to be found. Puzzle your way through level after level of cat fighting fun in this family favorite!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game. Pause and un-pauses game.

**A Key:** Jump.

**B Key:** Jump.

**C Key:** Jump.

7

### Golden Axe



It is a dark time in the Land of Yuria as the evil Death Adder has invaded, kidnapped the princess and seized the Golden Axe. Devastation alone lays in his wake. Three powerful heroes, each with distinct fighting styles, have emerged in a desperate attempt to bring justice to Yuria and free the princess. It will take all of the brawn and magic they can muster just to stand a chance of defeating Death Adder! They vow to save the princess or die trying! The rest is up to you.

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Use magic.

**B Key:** Attack.

**C Key:** Jump.

8

### Golden Axe III



Vanquished in Golden Axe I, the Death Adder has been defeated by our heroes. Unfortunately, another evil force, known as the Dark Guild, has risen to take his place. With the Golden Axe now in the Dark Guild's possession, our three heroes are once again called to action to retrieve the Golden Axe for mankind. To meet this new challenge, they must use all of their unique fighting skills and spells to save the land from chaos. Fighting has never been so much fun!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.


Pause and un-pauses game.

**A Key:** Use magic.

**B Key:** Attack.

**C Key:** Jump.

### Jewel Master



The peaceful kingdom of Mythgard seemed blessed for all time. Then the Demon Lord, the Mad, came to power and it seemed that all good was gone forever. Jewel Master, weaver of the Elements, was summoned to possess magical rings of great power and to use these rings to conjure spells with which to defeat the legions of Evil. As the Jewel Master, you must seek out the remaining rings, reclaim the Elemental Blade, and strike down Jarnage the Mad. Only by wielding the Elemental Blade can Mythgard be restored to its former glory!

**Directional Pad (D-Pad):** Control the direction.

Long presses the Up Key for the attack upward.

**Start Key (Start):** Start game.

Pause and un-pauses game.

**A Key:** Select the ring options in the left side.

**B Key:** Select the ring options in the right side.

**C Key:** Negative.

9

### Shadow Dancer



Union Lizard, a vast crime empire, has taken over New York. As Shadow Dancer, a master of martial arts, you must do battle in the name of justice. Using all of your kung-fu skills and the help of your faithful dog, it is up to you to stop the evil Ninja's of Union Lizard once and for all and regain the honor of a slain friend. Once New York is safe, you must fight the mighty Lizard King himself to achieve ultimate victory!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start game.

Pause and un-pauses game.


**A Key:** Use the master skill.

**B Key:** Attack.

**C Key:** Jump.

10

### Sonic the Hedgehog



Sonic the Hedgehog is a side scrolling race to save Sonic's animal friends, who have been captured by the evil Dr. Robotnik. Using great speed and a spin attack, Sonic brings plenty of attitude and looping, jumping, super-speed fun. Sonic the Hedgehog is on of the fastest and most entertaining games you can find! Save Sonics friends and special 3-D levels provide an amazing bonus!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start game.

Pause and un-pauses game.

**A Key:** Jump.


Press A key and the "down" key of the D-pad for speeding up the running.

**B Key:** Jump.

**C Key:** Jump.

11

### Sonic the Hedgehog 2



Sonic is back and once again he must face the evil Dr. Robotnik and his attempt to conquer the world. In order to achieve his goal, Dr. Robotnik captures all of the animals he can find and transforms them into robots to do his bidding. Sonic must defeat Dr. Robotnik and save his friends. The action has never been more fast or furious than this!

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start game.

Pause and un-pauses game.

**A Key:** Jump.


Press A key and the "down" key of the D-pad for speeding up the running.

**B Key:** Jump.

**C Key:** Jump.

12

### Street Fighter II – The New Challengers



Street Fighter II was the first one-on-one fighting game to give players a choice from a variety of player characters with different moves. Each player character has a fighting style with approximately 30 or more moves as well as two or three special attacks per character.

**Directional Pad (D-Pad):** Control the direction.

**Start Key (Start):** Start the game.

Pause and un-pauses game.

**A Key:** Light Kick.

**B Key:** Medium Kick.